



Zum Lausbühl 3 · D - 79227 Schallstadt Tel. +49 (0) 7664/50 99 00 - 0 · Fax +49 (0) 7664/50 99 00- 99 info@ariana-industrie.de · www.ariana-industrie.de

Special Mono Mixing Unit

A mixing unit is essential for mixing emulsions and grinding solutions. By means of a needle valve, the ARIANA Special Mono Mixing Unit allows for fast and precise adjustment of the emulsion concentration of liquid coolants and lubricants. In this way, it is possible to mix liquids using optimum concentrations.



Order no. 0512002

The Special Mono Mixing Unit has one water inlet and one concentrate inlet. Once the optimum mixing ratio has been determined, the user can always rely on this ratio being the case. Of course, it is possible to change the mixing ratio at any time. For safety reasons, a return valve is installed on the water inlet side to prevent any suctioning into the potable water system.

The Special Mono Mixing Unit is the simplest version in the mixing unit range. Quick and Order no. 0512002 simple installation on a barrel is possible thanks the barrel lid screw connection set. The unit is compact and extremely easy to handle.

Special Mono Mixing Unit with barrel lid screw connection



Technical data

Water inlet	1/2"
Concentrate inlet	3/8"
Mixed liquid outlet	1/2"
Mixing volume (approx.) I/h	270